



How to Configure Tab Wi-Fi Setting


1. open **Settings** and go to **Wireless & networks > Wi-Fi**. Enable **Wi-Fi**



2. Select the appropriate SSID




3. Enter the Password



4. then click the “Show advanced options” > IP Settings > Statics

a. Now enter


- i. IP Address :- 192.168.x.xx
- ii. Gateway :- 192.168.x.xx
- iii. Network Prefix Length :- 24
- iv. DNS 1 :- 192.168.x.xx
- v. DNS 2 :- (Optional)




Click The Save Button.

How to Configure Andon System App


1. Run the “Andon_System” App
2. Click the "CREATE DOWNTIME" button (3 Seconds)




3. Enter the Password and click the “yes” Button



4. Enter SSID, Server IP (Andon PC IP),Unit ID



5. Enable the tower light and enter the “Unit IP”



6. Finally Click the SAVE AND CLOSE Button And again run the Andon_System APP